


卡片尺寸：宽 11.5cm\*高 19cm

出血尺寸：左、右、上、下各 0.3cm





## 温馨提示 REMINDER

Kemove 提倡环保节能 ，在全球发售的 kemove 系列“不再提供纸质说明书”，可在 [www.kemove.com](http://www.kemove.com) 官网进行说明书下载以及 kemove control hub 首页右上角找到多国语言电子版说明书。

Kemove advocates environmental protection and energy saving. The Kemove series, which are released globally, "is no longer available in paper manuals". The manual can be downloaded from the official website [www.kemove.com](http://www.kemove.com) as well as found in the upper right corner of the homepage of the Kemove control hub.

Kemove defiende la protección del medio ambiente y el ahorro de energía. La serie Kemove, que se comercializa en todo el mundo, "ya no está disponible en manuales en papel". El manual puede descargarse del sitio web oficial [www.kemove.com](http://www.kemove.com), así como encontrarse en la esquina superior derecha de la página de inicio del centro de control de Kemove.

Kemove выступает за защиту окружающей среды и энергосбережение. Серия Kemove, выпущенная по всему миру, «больше не доступна в бумажных руководствах». Руководство можно загрузить с официального веб-сайта [www.kemove.com](http://www.kemove.com), а также найти в правом верхнем углу домашней страницы центра управления Kemove.

Kemove setzt sich für Umweltschutz und Energieeinsparung ein. Die Kemove-Serie, die weltweit veröffentlicht wird, „ist nicht mehr in Papierhandbüchern erhältlich“. Das Benutzerhandbuch kann auf der offiziellen Website [www.kemove.com](http://www.kemove.com) heruntergeladen werden und ist auch in der oberen rechten Ecke der Startseite der Kemove-Steuerzentrale erhältlich.

Kemove défend toujours la protection de l'environnement et les économies d'énergie. La série Kemove, qui est publiée dans le monde entier, « n'est plus disponible dans les manuels papier ». Le manuel peut être téléchargé sur le site officiel [www.kemove.com](http://www.kemove.com) ainsi que dans le coin en haut à droite de la page d'accueil du centre de contrôle Kemove.

Kemove sostiene la protezione dell'ambiente e il risparmio energetico. La serie Kemove che viene rilasciata in tutto il mondo, "non è più disponibile nei manuali cartacei". Il manuale può essere scaricato dal sito ufficiale [www.kemove.com](http://www.kemove.com) e anche trovato nell'angolo in alto a destra della homepage dell'hub di controllo Kemove.

Kemove はエコのために、紙質の手順書を提供するのが中止した。公式サイ [www.kemove.com](http://www.kemove.com) で手順書ダウンロードしていて、及び kemove control hub のトップページの右上で手順書が探しています。



# KEMOVE K68 三模功能说明书

三模功能分别为有线模式、2.4G 模式、蓝牙模式



## KEMOVE K68 three mode function instructions

The three mode function are wired mode, 2.4G mode and Bluetooth mode respectively

### 2.4G 模式 2.4G mode

拨动侧面开关打开 2.4G 模式 / 同时打开电源，按 Fn+G 匹配 2.4G 模式；

Toggle the side switch to turn on the 2.4G mode / turn on the power at the same time. Then press Fn+G to match the 2.4G mode

### BT 蓝牙模式 Bluetooth mode

侧面开关切换到蓝牙模式 / 同时打开电源（有线下不可用）；

Fn+Z=BT1 (长按 3 秒 Z 键红蓝灯交替闪烁，蓝牙处于配对状态，配对过的，再轻按一次，则是回链)；

Fn+X=BT2 (长按 3 秒 X 键红蓝灯交替闪烁，蓝牙处于配对状态，配对过的，再轻按一次，则是回链)；

Fn+C=BT3 (长按 3 秒 C 键红蓝灯交替闪烁，蓝牙处于配对状态，配对过的，再轻按一次，则是回链)；

Turn on the side switch to Bluetooth mode/turn on the power at the same time (not available in wired mode).

Fn+Z=BT1. Press and hold the Z button for 3 seconds, the red and blue lights flash alternately, and the Bluetooth is in the pairing state. If paired already, tap again to reconnect.

Fn+X=BT2. Press and hold the X button for 3 seconds, the red and blue lights flash alternately, and the Bluetooth is in the pairing state. If paired already, tap again to reconnect.

Fn+C=BT3. Press and hold the C button for 3 seconds, the red and blue lights flash alternately, and the Bluetooth is in the pairing state. If paired already, tap again to reconnect.

### 切换说明 / Reminder :



键盘处于当前蓝牙状态时，FN+Z/X/C 可直接切换链接蓝牙设备。

When the keyboard is in the Bluetooth mode, pressing FN+Z/X/C can directly switch the connected devices.



有线模式下无法使用 FN+Z/X/C 去链接蓝牙设备。

In wired mode, FN+Z/X/C cannot be used to connect to Bluetooth devices.



自动休眠默认 5 分钟关背光，30 分蓝牙断开。

The keyboard will automatically turn off the backlight and enter sleep mode after 5 minutes of inactivity. Bluetooth will automatically disconnect if keyboard is not used for 30 minutes.




mac/win 切换开关，切换键盘系统布局。

Use the mac/win switch to adjust the keyboard layout.

### 电量显示 / Power display :

有线模式下

FN+右alt



In wired mode:

FN+Right ALT

蓝牙模式下

FN+右alt



In Bluetooth mode:

FN+Right ALT

### FN 组合功能键 / FN Combination function key :

FN+J=⏸	FN+K=⏪	FN+L=⏩	FN+M=🔊	FN+<=⏮	FN+>=⏭
FN+1=F1	FN+2=F2	FN+3=F3	FN+4=F4	FN+5=F5	FN+6=F6
FN+7=F7	FN+8=F8	FN+9=F9	FN+0=F10	FN+_ =F11	FN+ =F12
FN+U=Print Screen	FN+=Insert	FN+O=Pause	FN+_ =home	FN+ =home	
FN+Win=Win key to lock/unlock	FN+Space=FN key function lock	FN+[=Scroll lock (1 turns red)	FN+ =Hardware lighting switch		
FN+b=press and hold for five seconds to restore the keyboard to factory default settings	FN+tab=Switch the keyboard light strip color				
FN+↓=The brightness of the light is weakened	FN+↑=Increase the brightness of the light	FN+>= speed up the lighting effect			
FN+backspace=turn off the light effect	FN+Enter=Enter the power saving mode	FN+]=software lighting switching			
FN+right shift=Switch the color of the default lighting effect of the keyboard	FN+<=The speed of the light effect becomes slower				
FN+capslock=Switch keyboard light with light effect	FN+Q=keyboard switch to profile1	FN+W=keyboard switch to profile2			
FN+E=keyboard switch to profile3	FN+R=keyboard switch to profile4	FN+T= switch back to standard layer (Cannot set macro command)			